



# instruction sheet 1

window unit

## The A/C-OK System for indoor coils

will ensure that the indoor part of your air conditioning system is clean. Please read this sheet and all labels carefully before using the product. We recommend that an A/C unit is cleaned at least twice a year at six monthly intervals.



1 Switch the unit off ...



2 ...disconnect from the electrical supply



3 Open the air inlet louvre.



4 Remove all filters (primary, and secondary if present).

Please cover any furnishings/electrical equipment that may be damaged during the cleaning process. Or use an **AC-OK Cleaning Cover...**



4 Place and fix an AC-OK Cleaning Cover around the unit...




5 ...making sure the drain tube discharges into a suitable container.



6 Spray AC-OK into the coil starting at the top in a corner.



7 Work down and across in a methodical manner. Keep Sprayer head within 5cm of the coil.



8 Keep coil wet for 10 minutes to obtain maximum cleaning.



9 Clean the drain tray as required by spraying with AC-OK if accessible.



10 Place an AC-OK Treatment Tablet in the condensate tray, if accessible.



11 Clean the filter with a vacuum cleaner, reassemble the unit, plug in and switch on.

**No need to rinse.** Used product and contamination will drain away as normal. Continue cleaning until the product run-off from the coil is clear.

